

ACCESSORY SWITCHPOUCH

For-Pour-Für-Voor-Para-Per
nintendo **SWITCH™**



INFORMATION

REFERENCE : **SWITCHPOUCH**

PACKAGING : **CARDBOARD**

COLOUR : **BLACK**

SIZE (L x H x W > MM) : **TBC**

OUTER CARTON QUANTITY : **TBC**

INNER CARTON QUANTITY : **TBC**

WEIGHT (G) : **TBC**

EVA CARRY CASE

- Rugged EVA case which holds your Nintendo SWITCH™ tablet
- Soft padding on the inside to prevent scratches on the tablet
- Four elastic loops to hold game cartridges
- Second pouch holds 2 x Joy-Con controllers and the charging cable

